

Specifications:


- battery: 3000mAh (11,1Wh); Li-Ion
- built-in energy gauge
- heating element: 14W - carbon fiber
- the heating element is located at the back of the belt
- modes: 33% (LO), 66% (MED), 100% (HI)
- working time: 8h (LO), 4h (MED), 3h (HI)
- fabric: outer: nylon, lining: polyester
- charger: 12V, 1A
- sizes: S, L
- weight without batteries: 200g
- weight with battery: 310g

Features:

- The heating element is constructed from carbon fibres offering extraordinary reliability and durability as well as medical properties, thanks to infrared waves
- A safe and economic Li-Poly battery provides a long time of operation of the heating system
- A pocket for storing the battery offers you comfort of use every day
- A large surface area of the heating element evenly distributes the heat, soothing and heating your body
- Thanks to the Velcro fastening, the belt may be adjusted within a wide range of waist sizes

Cleaning and maintenance

The heating element used in is resistant to moisture. However, strong laundry detergent can cause mechanical damage of the heating element . Therefore, we recommend surface cleaning with a cloth or brush with a small amount of detergent and gentle rinsing . If you need a more powerful washing, tightly wrap the end of the power cord. Do not clean with battery connected to them !



Important:

Before first use, fully charge the battery.

If the battery is stored for long periods without use, it should be fully charged before storage and charging should be repeated every 3 months.

If there is mechanical damage to any items, immediately turn off the device and remove the battery . The defective part must be sent to the service for repair or replacement .

**RoHS
Compliant**



USER MANUAL

Charging the internal battery

Connect batteries to the charger socket and then plug the charger to the electricity outlet. Charging time is approximately 5-6 hours.

Turning on and operation

Each time before turning on, make sure that the built-in connection cable is not mechanically damaged. Also make sure that the connected battery is free of mechanical damage. Connect the battery to the built-in cable. Place the battery in your pocket and zip it up. To start the heating press and hold the POWER button for 2 seconds. Device will turn on with the heating power at 100%. Another short press of the POWER button toggles the heating power to 66%, 33% and again 100%, which is indicated by lighting corresponding LED lights. To turn off the heat press and hold the POWER button

