

## Specifications:

- battery: 2100mAh (7,77Wh); Li-Poly
- built-in energy gauge
- heating element: 8W - carbon fiber
- the heating element is located all around the palm
- modes: 33% (LO), 66% (MED), 100% (HI)
- working time: 6h (LO), 3h (MED), 2h (HI)
- works with touch screens
- fabric: outer: natural leather, lining: polyester
- charger: 8.4V, 1A
- sizes: L, XL
- weight without batteries: 290g
- weight with battery: 460g
- convenient case included in the set

## Features:

- The heating element is constructed from carbon fibres offering extraordinary reliability and durability as well as medical properties, thanks to infrared waves
- A safe and economic Li-Poly battery provides a long time of operation of the heating system
- A pocket for storing the battery offers you comfort of use every day
- The gloves are made of natural cow leather and are insulated by the Thinsulate fabric patented by the 3M group
- The heating element is located all around the palm, thanks to which your palms will remain comfortably warm all the time
- The current-conducting filament on the thumb and the index finger allows for using touchpads without the need to take off the gloves

## Cleaning and maintenance

The heating element used in is resistant to moisture. However, strong laundry detergent can cause mechanical damage of the heating element. Therefore, we recommend surface cleaning with a cloth or brush with a small amount of detergent and gentle rinsing. If you need a more powerful washing, tightly wrap the end of the power cord. Do not clean with battery connected to them!



## Important:

Before first use, fully charge the battery.

If the battery is stored for long periods without use, it should be fully charged before storage and charging should be repeated every 3 months.

If there is mechanical damage to any items, immediately turn off the device and remove the battery. The defective part must be sent to the service for repair or replacement.



# USER MANUAL

## Charging the internal battery

Connect batteries to the charger socket and then plug the charger to the electricity outlet. Charging time is approximately 5-6 hours.

## Turning on and operation

Each time before turning on , make sure that the built- in connection cable is not mechanically damaged. Also make sure that the connected battery is free of mechanical damage. Connect the battery to the built-in cable. Place the battery in your pocket and zip it up. To start the heating press and hold the POWER button for 2 seconds. Device will turn on with the heating power at 100%. Another short press of the POWER button toggles the heating power to 66%, 33% and again 100%, which is indicated by litting corresponding LED lights. To turn off the heat press and hold the POWER button

